Manuals+

User Manuals Simplified.

SAMSUNG Galaxy S21 FE 5G Smartphone User Guide

January 17, 2022January 19, 2022

Home » **Samsung** » SAMSUNG Galaxy S21 FE 5G Smartphone User Guide 📄

SAMSUNG

Quick Start Guide

cricket® wireless

SAMSUNG Galaxy S21 FE 5G

GH68-53776A Printed in Korea

Contents [**hide**]

Getting to know your Galaxy S21 FE 5G

Unlock your phone
Press the **Side** key and swipe up on the screen.

To view the User Manual on the device, tap **Settings** > **Tips and help** .

Phone setup

Your SIM card may be pre-installed.

Insert a SIM card
Use the SIM tool to open the SIM tray and insert the SIM card into the tray with gold contacts facing up.

Charge your phone
Before turning on your phone, charge it fully.

Use only charging devices and batteries approved by Samsung. Samsung accessories are designed for your device to maximize battery life. Using other accessories may invalidate your warranty and cause damage.

Smart Switch

Easily transfer photos, videos, music, apps, and more with Samsung Smart Switch™. Select Smart Switch during setup, or open it later from the Home screen by swiping up for Apps and tapping **Settings > Accounts and backup** **> Bring data from old device**.

Visit **samsung.com/smartswitch** to learn more.

Touch screen

Navigate your phone

- From the Home screen, swipe up or down to access Apps.
- Tap Recent ||| to view recently viewed apps.
- Tap Home ⬭ at any time to return to the main Home screen.
- Tap **Back** ‹ to return to the previous screen.

Notification panel

Swipe down from the top of the display to get quick access to alerts including new messages, emails, and software updates.


Personalize

To personalize your home screen with apps, widgets, and themes, tap and hold a blank space on a home screen.

- **To move or delete a widget from a Home screen:**
- To move a widget or app, hold and drag it to a new location
- To delete a widget or app, hold then tap Remove.

Messages

Send a message

1. From the Home screen, tap **Messages** 💬 > **New message** 💬.
2. Enter a phone number or contact name in the **Recipient** field.
3. Tap **Enter the message** and enter your text or touch and hold 🎙️ to create an audio message.
4. Tap 🔵 to send the message.

Email

Email setup

1. From the Home screen, swipe up for **Apps** and then tap the **Microsoft** folder > **Outlook** .
2. Tap **ADD ACCOUNT** and follow the prompts to sign in.

Create and send an email message

1. From the home screen, swipe up for **Apps,** and then tap **Outlook** .
2. Tap to compose a message.
3. Tap to send a message.

Camera & video

Take a Picture

From the Home screen, tap Camera .

- Tap to take a photo.
- Pinch to zoom in or out.
- Tap or capture a wider area.
- Tap or swipe up to take selfies.
- Swipe right or left to select a shooting mode.

Record a Video

From the Home screen, tap **Camera** **,** then swipe left for **VIDEO.**

- Tap to start recording.
- Tap or swipe up to record selfies.
- Tap to capture a picture while recording.

- Tap ⬨ or ⬨ capture a wider area.
- Tap ⏸ to pause recording.
- Tap ⏹ to end recording.

Note: Press the Side key twice to quickly launch the camera.

Bixby

Bixby helps you unlock the full potential of your Samsung device. By learning what you like and working with your favorite apps.
To launch **Bixby,** press and hold the Side key and follow the prompts.

Apps and features

These apps and features make using your phone even better!

myCricket: Access billing, make a quick payment, view usage, and access support.

Visual Voicemail: Quickly view, access, and playback your voicemail messages, easily save important numbers to your Favorites lists, and respond to messages by calling back or texting.

theSCOOP: Get news, local weather, sports scores, entertainment, and more right to your phone.

More information

On the web
Detailed support information, including device specifications and the full user manual, are available at **cricketwireless.com/support/devices**.

On the phone

- Call Customer Care at **1-855-246-2461**
  or

- Dial **611** from your phone

Accessories

Cricket offers a full line of accessories. For more information, visit **cricketwireless.com/shop/accessories** or visit your local Cricket retailer.

© 2021 Samsung Electronics America, Inc. Samsung & Samsung Galaxy have registered trademarks of Samsung Electronics Co., Ltd. Appearance of the device may vary. If you use a screen protector, make sure it allows for use of touch-screen features.

© 2021 Cricket Wireless LLC. All rights reserved. Cricket and the Cricket logo are trademarks under license to Cricket Wireless LLC.

Documents / Resources

SAMSUNG Galaxy S21 FE 5G Smartphone [pdf] User Guide
Galaxy S21 FE 5G, Smartphone, Galaxy S21 FE 5G Smartphone, Mobile Phone, Phone

Related Manuals / Resources

SAMSUNG Galaxy S20 FE 5G User Manual

SAMSUNG Galaxy S20 FE 5G User Manual - Download [optimized]
SAMSUNG Galaxy S20 FE 5G User Manual -…

SAMSUNG Galaxy S21 5G Smartphone User Guide

Quick Reference Guide Printed in Korea GH68-52911A Samsung Care Samsung Premium CarePick the time and place and a…

SAMSUNG Galaxy S20 FE 5G UW User Manual

SAMSUNG Galaxy S20 FE 5G UW User Manual - Download [optimized]
SAMSUNG Galaxy S20 FE 5G UW User…

Samsung Galaxy S20 FE 5G Smart Watch User Manual

Samsung Galaxy S20 FE 5G Smart Watch User Manual - Optimized PDF
Samsung Galaxy S20 FE 5G Smart…

Manuals+,

- **home**
- **privacy**