




5



	A	B	C	D	E	F	G	H
UE43AU71**	963,9 mm (963.9 mm)	558,9 mm (558.9 mm)	59,6 mm (59.6 mm)	627,8 mm (627.8 mm)	192,5 mm (192.5 mm)	108 cm (108 cm)	8,1 кг (8.1 kg)	8,3 кг (8.3 kg)
UE50AU71**	1116,8 mm (1116.8 mm)	644,2 mm (644.2 mm)	59,9 mm (59.9 mm)	719,1 mm (719.1 mm)	250,2 mm (250.2 mm)	125 cm (125 cm)	11,4 кг (11.4 kg)	11,6 кг (11.6 kg)
UE55AU71**	1230,5 mm (1230.5 mm)	707,2 mm (707.2 mm)	59,9 mm (59.9 mm)	783,3 mm (783.3 mm)	250,2 mm (250.2 mm)	138 cm (138 cm)	13,9 кг (13.9 kg)	14,2 кг (14.2 kg)

*: 0-9, A-Z



	VESA A x B (mm) VESA A x B (mm)	C (mm) C (mm)	D x 4
UE43AU71**	200 x 200	20-22	M8
UE50AU71**			
UE55AU71**			

*: 0-9, A-Z

SAMSUNG

Краткое руководство по установке
QUICK SETUP GUIDE

Жылдам орнату нұсқаулығы

Короткий посібник зі встановлення


О'рnatish bo'yicha qisqacha qo'llanma

AU71** 43"-55"




Не касайтесь экрана
Do not touch the screen
Не торкайтесь екрану
Экранды тиеңіз
Ekranga tegmang

43"
-
50"




55"







	USB		USB +\leftrightarrow
	OPTICAL		
	ARC		HDMI (eARC)
			HDMI
			LAN
			ANT




1



2



3



4

43"

50"-55"

