Inspiron 15 3525

Setup and Specifications



Notes, cautions, and warnings

(i) NOTE: A NOTE indicates important information that helps you make better use of your product.

CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

MARNING: A WARNING indicates a potential for property damage, personal injury, or death.

© 2022-2023 Dell Inc. or its subsidiaries. All rights reserved. Dell Technologies, Dell, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

Contents

Chapter 2: Views of Inspiron 15 3525	
Right	
Left	
Тор	
Display	
Bottom	10
Service Tag	
Battery charge and status light	11
Chapter 3: Specifications of Inspiron 15 3525	
Dimensions and weight	
Processor	
Chipset	
Operating system	13
Memory	13
External ports	14
Internal slots	14
Wireless module	15
Audio	
Storage	
Media-card reader	
Keyboard	
Camera	17
Touchpad	17
Power adapter	
Battery	
Display	
Fingerprint reader (optional)	
GPU—Integrated	
GPU—Discrete	21
Hardware security	
Operating and storage environment	21
Chapter 4: ComfortView	23
Chapter 5: Keyboard shortcuts of Inspiron 15 3525	
Chapter 6: Getting help and contacting Dell	26

Set up your Inspiron 15 3525

(i) NOTE: The images in this document may differ from your computer depending on the configuration you ordered.

1. Connect the power adapter and press the power button.



NOTE: To conserve battery power, the battery might enter power saving mode. Connect the power adapter and press the power button to turn on the computer.

2. Finish operating system setup.

For Ubuntu:

Follow the on-screen instructions to complete the setup. For more information about installing and configuring Ubuntu, see the knowledge base articles 000131655 and 000131676 at www.dell.com/support.

For Windows:

Follow the on-screen instructions to complete the setup. When setting up, Dell recommends that you:

- Connect to a network for Windows updates.
 - () NOTE: If connecting to a secured wireless network, enter the password for the wireless network access when prompted.
- If connected to the internet, sign-in with or create a Microsoft account. If not connected to the internet, create an offline account.
- On the **Support and Protection** screen, enter your contact details.
- 3. Locate and use Dell apps from the Windows Start menu—Recommended.

Table 1. Locate Dell apps

Resources	Description
	Dell Product Registration Register your computer with Dell.
ТЩ.	Dell Help & Support Access help and support for your computer.
	SupportAssist
	SupportAssist is the smart technology that keeps your computer running at its best by optimizing settings, detecting issues, removing viruses and notifies when you need to make system updates. SupportAssist proactively checks the health of your system's hardware and software. When an issue is detected, the necessary system state information is sent to Dell to begin troubleshooting. SupportAssist is preinstalled on most of the Dell devices running Windows operating system. For more information, see SupportAssist for Home PCs User's Guide on www.dell.com/serviceabilitytools.
	Dell Update
↓	Updates your computer with critical fixes and latest device drivers as they become available. For more information about using Dell Update, see the knowledge base article 000149088 at www.dell.com/support.
	Dell Digital Delivery
	Download software applications, which are purchased but not pre-installed on your computer. For more information about using Dell Digital Delivery, see the knowledge base article 000129837 at www.dell.com/support.

Views of Inspiron 15 3525

Right



1. SD-card slot

Reads from and writes to the SD card. The computer supports the following card types:

- Secure Digital (SD)
- Secure Digital High Capacity (SDHC)
- Secure Digital Extended Capacity (SDXC)

2. USB 2.0 port

Connect devices such as external storage devices and printers. Provides data transfer speeds up to 480 Mbps.

3. Headset (headphone and microphone combo) port

Connect headphones or a headset (headphone and microphone combo).

Left



Figure 1. Chassis with USB Type-A port

1. Power-adapter port

Connect a power adapter to provide power to your computer and charge the battery.

2. Power and battery-status light

Indicates the power state and battery state of the computer.

Solid white—Power adapter is connected and the battery is charging.

Solid amber—Battery charge is low or critical.

Off—Battery is fully charged.

NOTE: On certain computer models, the power and battery-status light are also used for diagnostics. For more information, see the *Troubleshooting* section in your computer's *Service Manual*.

3. HDMI 1.4 port

Connect to a TV, external display or another HDMI-in enabled device. Provides video and audio output.

4. USB 3.2 Gen 1 port

Connect devices such as external storage devices and printers. Provides data transfer speeds up to 5 Gbps.

5. USB 3.2 Gen 1 port (optional for AMD Dali)

Connect devices such as external storage devices and printers. Provides data transfer speeds up to 5 Gbps.



Figure 2. Chassis with USB Type-C port

1. Power-adapter port

Connect a power adapter to provide power to your computer and charge the battery.

2. Power and battery-status light

Indicates the power state and battery state of the computer.

Solid white—Power adapter is connected and the battery is charging.

Solid amber—Battery charge is low or critical.

Off-Battery is fully charged.

NOTE: On certain computer models, the power and battery-status light are also used for diagnostics. For more information, see the *Troubleshooting* section in your computer's *Service Manual*.

3. HDMI 1.4 port

Connect to a TV, external display or another HDMI-in enabled device. Provides video and audio output.

4. USB 3.2 Gen 1 port

Connect devices such as external storage devices and printers. Provides data transfer speeds up to 5 Gbps.

5. USB 3.2 Gen 1 Type-C port (optional for Barcelo/Lucienne)

Connect devices such as external storage devices and printers. Provides data transfer speeds up to 5 Gbps.




1. Power button with optional fingerprint reader

Press to turn on the computer if it is turned off, in sleep state, or in hibernate state.

When the computer is turned on, press the power button to put the computer into sleep state; press and hold the power button for four seconds to force shut-down the computer.

If the power button has a fingerprint reader, place your finger on the power button to log in.




- **NOTE:** The highlighted area indicates the actual active fingerprint reader area and the image is for illustration purposes only.
- **NOTE:** You can customize power-button behavior in Windows. For more information, see *Me and My Dell* at www.dell.com/support/manuals.

2. Touchpad

Move your finger on the touchpad to move the mouse pointer. Tap to left-click and two fingers tap to right-click.

Display

CAUTION: The maximum operating angle for the display-panel hinge is 135 degrees.



1. Left microphone (optional)

Provides digital sound input for audio recording and voice calls.

2. Camera

Enables you to video chat, capture photos, and record videos.

3. Privacy shutter (optional)

Slide the privacy shutter to cover the camera lens and protect your privacy when the camera is not in use.

4. Camera-status light

Turns on when the camera is in use.


5. Right microphone

Provides digital sound input for audio recording and voice calls.

6. LCD panel

Provides visual output to the user.

Bottom



1. Speakers

Provide audio output.

2. Service Tag and regulatory labels


The Service Tag is a unique alphanumeric identifier that enables Dell service technicians to identify the hardware components in your computer and access warranty information. The regulatory label contains regulatory information of your computer.

3. Air vents

Air vents provide ventilation for your computer. Clogged air vents can cause overheating and can affect your computer's performance and potentially cause hardware issues. Keep the air vents clear of obstructions and clean them regularly to prevent build-up of dust and dirt. For more information about cleaning air vents, search for articles in Knowledge Base Resource at www.dell.com/support.

Service Tag

The service tag is a unique alphanumeric identifier that allows Dell service technicians to identify the hardware components in your computer and access warranty information.



Battery charge and status light

The following table lists the battery charge and status light behavior of your Inspiron 15 3525.

Table 2. Battery charge and status light behavior

Power Source	LED Behavior	System Power State	Battery Charge Level
AC Adapter	Off	S0 - S5	Fully Charged
AC Adapter	Solid White	S0 - S5	< Fully Charged
Battery	Off	S0 - S5	11-100%
Battery	Solid Amber (590+/-3 nm)	S0 - S5	< 10%

• S0 (ON) - System is turned on.

• S4 (Hibernate) - The system consumes the least power compared to all other sleep states. The system is almost at an OFF state, expect for a trickle power. The context data is written to hard drive.

• S5 (OFF) - The system is in a shutdown state.

3

Specifications of Inspiron 15 3525

Dimensions and weight

The following table lists the height, width, depth, and weight of your Inspiron 15 3525.

Table 3. Dimensions and weight

Description	Plastic	Aluminum
Height:		
Front height	16.96 mm (0.66 in.)	15.52 mm (0.61 in.)
Rear height	19.00 mm (0.74 in.)	17.50 mm (0.69 in.)
Width	358.50 mm (14.11 in.)	358.50 mm (14.11 in.)
Depth	235.60 mm (9.27 in.)	234.90 mm (9.24 in.)
Weight (i) NOTE: The weight of your computer depends on the configuration ordered and manufacturing variability.	Minimum - 1.83 kg (4.03 lb) Maximum - 1.90 kg (4.19 lb)	Minimum - 1.85 kg (4.08 lb) Maximum - 1.94 kg (4.27 lb)

Processor

The following table lists the details of the processors supported by your Inspiron 15 3525.

Table 4. Processor

Descriptio n	Option one	Option two	Option three	Option four	Option five	Option six	Option seven
Processor type	AMD Athlon Silver 3050U	AMD Ryzen 3 3250U	AMD Ryzen 3 5425U	AMD Ryzen 5 5500U	AMD Ryzen 5 5625U	AMD Ryzen 7 5700U	AMD Ryzen 7 5825U
Processor wattage	15 W	15 W	15 W	15 W	15 W	15 W	15 W
Processor core count	2	2	4	6	6	8	8
Processor thread count	2	4	8	12	12	16	16
Processor speed	2.30 GHz to 3.20 GHz	2.60 GHz to 3.50 GHz	2.70 GHz to 4.10 GHz	2.10 GHz to 4 GHz	2.30 GHz to 4.30 GHz	1.80 GHz to 4.30 GHz	2 GHz to 4.50 GHz
Processor cache	4 MB	4 MB	10 MB	8 MB	19 MB	8 MB	20 MB

Table 4. Processor (continued)

Descriptio n	Option one	Option two	Option three	Option four	Option five	Option six	Option seven
Integrated graphics	AMD Radeon Graphics	AMD Radeon Graphics	AMD Radeon Graphics	AMD Radeon Graphics	AMD Radeon Graphics	AMD Radeon Graphics	AMD Radeon Graphics

Chipset

The following table lists the details of the chipset supported by your Inspiron 15 3525

Table 5. Chipset

Description	Option one	Option two
Processors	AMD Athlon series	AMD Ryzen series
Chipset	Integrated	Integrated
DRAM bus width	Two channels, 64-bit	Two channels, 64-bit
Flash EPROM	16 MB	16 MB
PCIe bus	Up to Gen 3	Up to Gen 3

Operating system

Your Inspiron 15 3525 supports the following operating systems:

- Windows 11 Home, 64-bit
- Windows 11 Home in S-mode, 64-bit
- Windows 11 Pro, 64-bit
- Windows 11 Pro National Academic, 64-bit
- Ubuntu 20.04 LTS, 64-bit

Memory

The following table lists the memory specifications of your Inspiron 15 3525.

Table 6. Memory specifications

Description	Values
Memory slots	Two SODIMM
Memory type	DDR4
Memory speed	 3200 MHz - for AMD Ryzen3 5425U/Ryzen5 5625U/ Ryzen7 5825U 2400 MHz - for AMD Athlon and Ryzen3 3250U
Maximum memory configuration	16 GB
Minimum memory configuration	4 GB
Memory size per slot	4 GB, 8 GB, 16 GB

Table 6. Memory specifications (continued)

Description	Values
Memory configurations supported	 4 GB, 1 x 4 GB, DDR4, 2400 MHz for AMD Athlon/3200 MHz for AMD Ryzen 8 GB, 1 x 8 GB, DDR4, 2400 MHz for AMD Athlon/3200 MHz for AMD Ryzen 8 GB, 2 x 4 GB, DDR4, 2400 MHz for AMD Athlon/3200 MHz for AMD Ryzen, dual-channel 12 GB, 1 x 4 GB + 1 x 8 GB, DDR4, 2400 MHz for AMD® Athlon/3200 MHz for AMD® Ryzen 16 GB, 1 x 16 GB, DDR4, 2400 MHz for AMD Athlon/3200 MHz for AMD Ryzen 16 GB, 2 x 8 GB, DDR4, 2400 MHz for AMD Athlon/3200 MHz for AMD Ryzen 16 GB, 2 x 8 GB, DDR4, 2400 MHz for AMD Athlon/3200 MHz for AMD Ryzen, dual-channel

External ports

The following table lists the external ports of your Inspiron 15 3525.

Table 7. External ports

Description	Values	
Network port	N/A	
USB ports	 Two USB 3.2 Gen 1 ports (Dali) One USB 3.2 Gen 1 port (Barcelo/Lucienne) One USB 3.2 Gen 1 Type-C port (Barcelo/Lucienne) One USB 2.0 port 	
Audio port	One headset (headphone and microphone combo) port	
Video port	One HDMI 1.4 port	
Media-card reader	One SD card slot	
Power-adapter port	65 W AC adapter, 4.5 mm barrel-type	
Security-cable slot	N/A	

Internal slots

The following table lists the internal slots of your Inspiron 15 3525.

Table 8. Internal slots

Description	Values
M.2	 One M.2 2230 slot for Wi-Fi and Bluetooth card One M.2 slot for 2230/2280 for solid-state drive (i) NOTE: To learn more about the features of different types of M.2 cards, search in the Knowledge Base Resource at www.dell.com/support.

Wireless module

The following table lists the Wireless Local Area Network (WLAN) modules supported on your Inspiron 15 3525.

Table 9. Wireless module specifications

Description	Option one	Option two
Model number	Realtek RTL8821CE	MediaTek MT7921
Transfer rate	433 Mbps	1200 Mbps
Frequency bands supported	2.40 GHz/5 GHz	2.40 GHz/5 GHz
Wireless standards	 WiFi 802.11a/b/g Wi-Fi 4 (Wi-Fi 802.11n) Wi-Fi 5 (WiFi 802.11ac) 	 WiFi 802.11a/b/g Wi-Fi 4 (Wi-Fi 802.11n) Wi-Fi 5 (Wi-Fi 802.11ac) Wi-Fi 6 (WiFi 802.11ax)
Encryption	 64-bit/128-bit WEP AES-CCMP TKIP 	 64-bit/128-bit WEP AES-CCMP TKIP
Bluetooth	Bluetooth 5.0	Bluetooth 5.2

Audio

The following table lists the audio specifications of your Inspiron 15 3525.

Table 10. Audio specifications

Description		Dali	Barcelo
Audio controller		Realtek ALC3204	Realtek ALC3254
Stereo convers	ion	Supported	Supported
Internal audio ir	nterface	High definition audio interface	High definition audio interface
External audio interface		One headset (headphone and microphone combo) port	One headset (headphone and microphone combo) port
Number of spea	akers	Тwo	Тwo
Internal-speaker amplifier		Supported	Supported (Audio codec built-in amplifier)
External volume controls		Keyboard shortcut controls	Keyboard shortcut controls
Speaker output	:		
	Average speaker output	2 W	2 W
Peak speaker output		2.5 W	2.5 W
Subwoofer output		Not supported	Not supported
Microphone		Single digital microphone	Plastic : Single digital microphone Aluminum: Dual-array microphones

Storage

This section lists the storage options on your Inspiron 15 3525.

Your computer supports one of the following configurations:

- 2.5-in. 5400 RPM, SATA hard drive
- M.2 2230/2280 for solid-state drive

The primary drive of your computer varies with the storage configuration. For computers:

- 2.5-in. 5400 RPM, SATA hard drive
- M.2 2230/2280 for solid-state drive

Table 11. Storage specifications

Storage type	Interface type	Capacity
2.5-in. 5400 rpm, hard drive	SATA	Up to 2 TB
M.2 2230 solid-state drive	PCle NVMe 3x4	Up to 1 TB
M.2 2230 solid-state drive	PCle NVMe 4x4	Up to 1TB
M.2 2280 solid-state drive	PCle NVMe 4x4	Up to 2 TB
M.2 2280 solid-state drive, QLC	PCle NVMe 3x4	Up to 1 TB

Media-card reader

The following table lists the media cards supported by your Inspiron 15 3525.

Table 12. Media-card reader specifications

Description	Values	
Media-card type	One SD card	
Media-cards supported	 Secure Digital (SD) Secure Digital High Capacity(SDHC) Secure Digital Extended Capacity(SDXC) 	
NOTE: The maximum capacity supported by the media-card	reader varies depending on the standard of the media card	

() NOTE: The maximum capacity supported by the media-card reader varies depending on the standard of the media card installed in your computer.

Keyboard

The following table lists the keyboard specifications of your Inspiron 15 3525.

Table 13. Keyboard specifications

Description	Values	
Keyboard type	Carbon, Standard backlit keyboardCarbon, Standard non-backlit keyboard	
Keyboard layout	QWERTY	
Number of keys	 United States and Canada: 99 keys United Kingdom: 100 keys Japan: 103 keys 	

Table 13. Keyboard specifications (continued)

Description	Values	
Keyboard size	X=18.70 mm key pitch Y=18.05 mm key pitch	
Keyboard shortcuts	Some keys on your keyboard have two symbols on them. These keys can be used to type alternate characters or to perform secondary functions. To type the alternate character, press Shift and the desired key. To perform secondary functions, press Fn and the desired key. (i) NOTE: You can define the primary behavior of the function keys (F1–F12) changing Function Key Behavior in BIOS setup program.	

Camera

The following table lists the camera specifications of your Inspiron 15 3525.

Table 14. Camera specifications

Description		Plastic	Aluminum	
Nur	nber of cameras	One	One	
Car	nera type	HD RGB camera	FHD RGB camera	
Camera location		Front camera	Front camera	
Car	nera sensor type	CMOS sensor technology	CMOS sensor technology	
Car	nera resolution:			
	Still image	0.92 megapixel	2 megapixels	
Video		1280 x 720 (HD) at 30 fps	1920 x 1080 (FHD) at 30 fps	
Dia	gonal viewing angle:	78.60 degrees	82 degrees	

Touchpad

The following table lists the touchpad specifications of your Inspiron 15 3525.

Table 15. Touchpad specifications

Description		Values	
Touchpad res	solution:		
	Horizontal	> 300	
	Vertical	> 300	
Touchpad dir	nensions:		
	Horizontal	115 mm (4.52 in.)	
	Vertical	80 mm (3.15 in.)	

Table 15. Touchpad specifications (continued)

Description	Values
	For more information about touchpad gestures available on Windows, see the Microsoft knowledge base article at support.microsoft.com.

Power adapter

The following table lists the power adapter specifications of your Inspiron 15 3525.

Table 16. Power adapter specifications

Description	Values
Туре	65 W
Connector dimensions:	
External diameter	2.90 mm (0.11 in.)
Internal diameter	4.50 mm (0.17 in.)
Input voltage	100 VAC x 240 VAC
Input frequency	50 Hz x 60 Hz
Input current (maximum)	1.70 A
Output current (continuous)	3.34 A
Rated output voltage	19.50 VDC
Temperature range:	
Operating	0°C to 40°C (32°F to 104°F)
Storage	-40°C to 70°C (-40°F to 158°F)

Battery

The following table lists the battery specifications of your Inspiron 15 3525.

Table 17. Battery specifications

Description		Option one	Option two	
Battery type		3-cell, 41 Wh "smart" lithium ion	4-cell, 54 Wh "smart" lithium ion	
Battery voltage		11.25 VDC	15.0 VDC	
Battery weight (maximum)		0.19 kg (0.41 lbs)	0.24 kg (0.54 lbs)	
Battery dimensions:				
	Height	206.40 mm (8.12 in.)	271.90 mm (10.70 in.)	

Table 17. Battery specifications (continued)

Description		Option one	Option two	
	Width	82.00 mm (3.22 in.)	82.00 mm (3.22 in.)	
	Depth	5.75 mm (0.22 in.)	5.75 mm (0.22 in.)	
Temperature range:				
	Operating	 When charging battery: Initiate charging: 0°C to 45°C (32°F to 113°F) Upper limit for charging (maximum): 50°C (122°F) When discharging battery: Normal discharging: 0°C to 60°C (32°F to 140°F) Over temperature protection (maximum): 70°C (158°F) (i) NOTE: The battery does not allow discharge past this temperature. 	 When charging battery: Initiate charging: 0°C to 45°C (32°F to 113°F) Upper limit for charging (maximum): 50°C (122°F) When discharging battery: Normal discharging: 0°C to 60°C (32°F to 140°F) Over temperature protection (maximum): 70°C (158°F) (i) NOTE: The battery does not allow discharge past this temperature. 	
Battery operating time	Storage	-20°C to 60°C (-4°F to 140°F) Varies depending on operating conditions and can significantly	-40°C to 65°C (-40°F to 149°F) Varies depending on operating conditions and can significantly reduce under certair	
		reduce under certain power-intensive conditions.	power-intensive conditions.	
Battery charging time (approximate) i NOTE: Control the charging time, duration, start and end time, and so on using the Dell Power Manager application. For more information on the Dell Power Manager see, <i>Me and</i> <i>My Dell</i> on www.dell.com.		4 hours (when the computer is off)	4 hours (when the computer is off)	
Coin-cell battery		NA	NA	

CAUTION: Dell recommends that you charge the battery regularly for optimal power consumption. If your battery charge is completely depleted, connect the power adapter, turn on your computer, and then restart your computer to reduce the power consumption.

Display

The following table lists the display specifications of your Inspiron 15 3525.

Table 18. Display specifications

Description	Option one	Option two	Option three
Display type	High Definition (HD)	Full High Definition (FHD)	Full High Definition (FHD)
Touch options	No	No	Yes
Display-panel technology	Twisted Nematic (TN)	In-Plane Switching (IPS)	Wide Viewing angle (WVA)

Table 18. Display specifications (continued)

Description		Option one	Option two	Option three
Display-panel di (active area):	imensions			
Heigh	nt	193.54 mm (7.62 in.)	193.54 mm (7.62 in.)	193.60 mm (7.62 in.)
Width	٦	344.23 mm (13.60 in.)	344.23 mm (13.60 in.)	344.20 mm (13.55 in.)
Diago	onal	394.90 mm (15.50 in.)	394.90 mm (15.50 in.)	394.90 mm (15.54 in.)
Display-panel na resolution	ative	1366 × 768	1920 × 1080	1920 × 1080
Luminance (typ	ical)	220 nits	250 nits	220 nits
Megapixels		1.05 M	2.07 M	2.07M
Color gamut		NTSC 45% typical	NTSC 45% typical	NTSC 45% Typ.
Pixels Per Inch (PPI)		100	141	141
Contrast ratio (typical)		400:1	600:1	700:1
Response time (max)		20 ms	35 ms	35 ms
Refresh rate		60 Hz	120 Hz	60 Hz
Horizontal view angle		40 degrees (Left/Right)	80 degrees (Left/Right)	80 degrees (Left/Right)
Vertical view angle		al view angle 10 degrees (Up) / 30 degrees (Down)		80 degrees (Up/Down)
Pixel pitch		0.252 x 0.252 mm	0.17925 x 0.17925 mm	0.17925 x 0.17925 mm
Power consumption 4 (maximum)		4.20 W	4.20 W	4.6 W
Anti-glare vs glossy finish		Anti-glare	Anti-glare	Anti-glare

Fingerprint reader (optional)

The following table lists the specifications of the optional fingerprint-reader of your Inspiron 15 3525.

Table 19. Fingerprint reader specifications

Description	Values
Fingerprint-reader sensor technology	Capacitive
Fingerprint-reader sensor resolution	500 dpi
Fingerprint-reader sensor pixel size	108 x 88

GPU—Integrated

The following table lists the specifications of the integrated Graphics Processing Unit (GPU) supported by your Inspiron 15 3525.

Table 20. GPU—Integrated

Controller	Memory size	Processor
AMD Radeon Graphics	Shared system memory	 AMD Athlon Silver AMD Ryzen 3 AMD Ryzen 5 AMD Ryzen 7

GPU—Discrete

The following table lists the specifications of the discrete Graphics Processing Unit (GPU) supported by your Inspiron 15 3525.

Table 21. GPU—Discrete

Controller	Memory size	Memory type
NVIDIA GeForce MX550 (upsell)	2 GB	GDDR6

Hardware security

The following table lists the hardware security of your Inspiron 15 3525.

Table 22. Hardware security

Hardware security	
Nindows Hello - Fingerprint Reader (optional)	
Camera shutter (for metal laptop only)	

Operating and storage environment

This table lists the operating and storage specifications of your Inspiron 15 3525.

Airborne contaminant level: G1 as defined by ISA-S71.04-1985

Table 23. Computer environment

Description	Operating	Storage
Temperature range	0°C to 35°C (32°F to 95°F)	-40°C to 65°C (-40°F to 149°F)
Relative humidity (maximum)	10% to 90% (non-condensing)	0% to 95% (non-condensing)
Vibration (maximum)*	0.66 GRMS	1.30 GRMS
Shock (maximum)	110 G†	160 G†
Altitude range	-15.20 m to 3048 m (-49.80 ft to 10000 ft)	-15.20 m to 10668 m (-49.80 ft to 35000 ft)

Table 23. Computer environment (continued)

Description	Operating	Storage
	emperature ranges may differ among c ay impact the performance of specific c	

 \ast Measured using a random vibration spectrum that simulates user environment.

† Measured using a 2 ms half-sine pulse.

ComfortView

WARNING: Prolonged exposure to blue light from the display may lead to long-term effects such as eye strain, eye fatigue, or damage to the eyes.

Blue light is a color in the light spectrum which has a short wavelength and high energy. Chronic exposure to blue light, particularly from digital sources, may disrupt sleep patterns and cause long-term effects such as eye strain, eye fatigue, or damage to the eyes.

ComfortView mode can be enabled and configured using the Dell CinemaColor application.

ComfortView mode complies with TÜV Rheinland's requirement for low blue light displays.

Low blue light: Dell ComfortView software technology reduces harmful blue light emissions to make extended screen time easy on your eyes.

To reduce the risk of eye strain, it is also recommended that you:

- Position the display at a comfortable viewing distance between 20 and 28 inches (50 and 70 cm) from your eyes.
- Blink frequently to moisten your eyes, wet your eyes with water, or apply suitable eye drops.
- Look away from your display, and gaze at a distant object at 20 ft (609.60 cm) away for at least 20 seconds during each break.
- Take an extended break for 20 minutes every two hours.

Keyboard shortcuts of Inspiron 15 3525

NOTE: Keyboard characters may differ depending on the keyboard language configuration. Keys used for shortcuts remain the same across all language configurations.

Some keys on your keyboard have two symbols on them. These keys can be used to type alternate characters or to perform secondary functions. The symbol shown on the lower part of the key refers to the character that is typed out when the key is pressed. If you press shift and the key, the symbol shown on the upper part of the key is typed out. For example, if you press 2, 2 is typed out; if you press Shift + 2, @ is typed out.

The keys F1-F12 at the top row of the keyboard are function keys for multi-media control, as indicated by the icon at the bottom of the key. Press the function key to invoke the task represented by the icon. For example, pressing F1 mutes the audio (refer to the table below).

However, if the function keys F1-F12 are needed for specific software applications, multi-media functionality can be disabled by pressing Fn + Esc. Subsequently, multi-media control can be invoked by pressing Fn and the respective function key. For example, mute audio by pressing Fn + F1.

NOTE: You can also define the primary behavior of the function keys (F1–F12) by changing **Function Key Behavior** in BIOS setup program.

Table	24.	List	of	keyboard	shortcuts
-------	-----	------	----	----------	-----------

Function key	Primary behavior
F1	Mute audio
F2	Decrease volume
F3	Increase volume
F4	Play/Pause
F5	Toggle keyboard backlight (optional)
F6	Decrease brightness
F7	Increase brightness
F8	Switch to external display
F10	Print screen
F11	Home
F12	End

The Fn key is also used with selected keys on the keyboard to invoke other secondary functions.

Table 25. Secondary behavior

Function key	Secondary behavior
Fn + F1	Operating system and application specific F1 behavior
Fn + F2	Operating system and application specific F2 behavior
Fn + F3	Operating system and application specific F3 behavior
Fn + F4	Operating system and application specific F4 behavior
Fn + F5	Operating system and application specific F5 behavior
Fn + F6	Operating system and application specific F6 behavior
Fn + F8	Operating system and application specific F8 behavior

Table 25. Secondary behavior (continued)

Function key	Secondary behavior
Fn + F9	Operating system and application specific F9 behavior
Fn + F10	Operating system and application specific F10 behavior
Fn + F11	Operating system and application specific F11 behavior
Fn + F12	Operating system and application specific F12 behavior
Fn + PrtScr	Turn off/on wireless
Fn + B	Pause/Break
Fn + Insert	Sleep
Fn + S	Toggle scroll lock
Fn + H	Toggle between power and battery-status light/hard-drive activity light
Fn + R	System request
Fn + Ctrl	Open application menu
Fn + Esc	Toggle Fn-key lock
Fn + PgUp	Page up
Fn + PgDn	Page down
Fn + Home	Home
Fn + End	End

6

Getting help and contacting Dell

Self-help resources

You can get information and help on Dell products and services using these self-help resources:

Table 26. Self-help resources

Self-help resources	Resource location	
Information about Dell products and services	www.dell.com	
My Dell app	Deell	
Tips	·•	
Contact Support	In Windows search, type Contact Support, and press Enter.	
Online help for operating system	www.dell.com/support/windows	
	www.dell.com/support/linux	
Access top solutions, diagnostics, drivers and downloads, and learn more about your computer through videos, manuals and documents.	Your Dell computer is uniquely identified by a Service Tag or Express Service Code. To view relevant support resources for your Dell computer, enter the Service Tag or Express Service Code at www.dell.com/support. For more information on how to find the Service Tag for your computer, see Locate the Service Tag on your computer.	
Dell knowledge base articles for a variety of computer concerns	 Go to www.dell.com/support. On the menu bar at the top of the Support page, select Support > Knowledge Base. In the Search field on the Knowledge Base page, type the keyword, topic, or model number, and then click or tap the search icon to view the related articles. 	

Contacting Dell

To contact Dell for sales, technical support, or customer service issues, see www.dell.com/contactdell.

(i) NOTE: Availability varies by country/region and product, and some services may not be available in your country/region.

() NOTE: If you do not have an active Internet connection, you can find contact information about your purchase invoice, packing slip, bill, or Dell product catalog.