

WEEE Number: 80133970

INSTALLATION INSTRUCTION

VT-768 LED SOLAR LIGHT



INTRODUCTION

Thank you for selecting and buying V-TAC LED product. V-TAC will serve you the best. Please read these instructions carefully before starting the installing and keep this manual handy for future reference. If you have any other query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best.



SPECIFICATION

| SKU | 7523 |
|----------------------|-----------------------------------|
| Power/Lumen | 3W / 400LM |
| LEDs | SMD2835*30PCS |
| Li-ion Battery | 2000mAh / 3.7V, 18650 Replaceable |
| Solar Panel | 2.3Wp, Mono-crystalline silicon |
| Working Mode | 3 different lighting modes |
| Detection Angle/Area | 60°/ 2-6Mtr |
| Visible Distance | 6-7Mtr |
| IP Degree | IP 65 |
| Lifespan | 35,000hrs |
| Installation Height | 2-4Mtr |

FEATURES





INSTALLATION




- 1. Drill 3 holes Φ 6mm as advised in above picture.
- 2. Fix 3 expansion plugs into the holes.
- 3. Fix a screw to the lower expansion plug with notch onto the screw.
- 4. Straighten the whole lamp and fasten the upper screws.
- 5. Press the back button to switch on lamp, adjust to the demanded working mode.

NOTICE

- 1. Pls install this light onto flat surface directiona
- 2. The lamp will light up when the environmental brightness is less than 30lux.
- 3. Inside battery is replaceable, 18650 Li-ion battery
- 4. Lamp need to be installed 2-4Mtr from the ground.



WORKING MODES



WARRANTY

- This product is warranted from manufacturing defect only.
- The warranty does not apply to damage caused by incorrect installation or abnormal wear and tear.
- The company gives no warranty against damage to any surface due to incorrect removal and installation of the product.